



## Assembly of the level rod and crossbeam

1 - Compress spring



2 - Slide rod under washer



3 - Slide rod up and over bolt head -



4 - and under second washer



Finished assembly



Another view



5 - Insert crossbeam



6 - Place crossbeam on saddle



7 - and clamp with knob



Take care not to over tighten fasteners.

Loosen allen bolts in the rod bracket if it does not slide freely on the crossbeam.

