



Emriver head scale paper scales

1. Cut out rectangle.
2. Attach Scotch tape at points shown.
3. Align on plastic head scale rod and roll around it.
4. Insert in rod into head scale tube, replace foam spacer and cap.